




Large Counter Display Kit

Parts List & Assembly Instructions



Scan to watch the
assembly video









Weight: 4 lbs

For inquiries, contact us at
support@tiptappay.com

Updated: 08/12/25
[EN]

Parts List

GASKET SET						
Front Gasket	Back Gasket	Device	Signage	Display Base	10ft Cable	Wall Plug
						
X3	X3	X3	X1	X1	X1	X1
Make Your Display Portable! With <u>Battery Accessory kits</u> Contact sales@tiptappay.com to learn more. To be ordered separately.						


Safety Precautions

- 1). Please only use the components supplied by tiptap to power your devices and charge your battery.
- 2). If a cable is frayed or worn, please do not use it. Contact support@tiptappay.com and we will replace it.

Installation Steps


- 1

Place printed signage on the front side of the base and lineup at the cutout hole.




- 2

Place device in the front gasket and put it through the front of the signage and base. Make sure the device denomination is right side up.




- 3

Connect the back gasket with the front gasket until snug. Repeat steps 2 and 3 until all devices are in place.



- 4


Connect the USB-C to the device and the USB-A cable to the wall plug.





Kit grand présentoir de comptoir

Liste de pièces et instructions
d'assemblage



Poids: 4 lbs






Pour toute demande de
renseignements, contactez-
nous à l'adresse suivante :
support@tiptappay.com

Scan to watch the
assembly video



Mise à jour: 08/12/25
[FR]

Liste des pièces

SET DE GASKET						
Joint avant	Joint arrière	Appareil	Signe	Socle d'affichage	câble à 3 voies	Prise murale
						
X3	X3	X3	X1	X1	X1	X1
Rendez votre support de sol portable! avec les <u>kits d'accessoires pour batteries</u>. Contactez sales@tiptappay.com pour en savoir plus. A commander séparément.						


Précautions de sécurité

- 1). N'utilisez que les composants fournis par tiptap pour allumer votre appareil et charger votre batterie.
- 2). Si un câble est effiloché ou usé, ne l'utilisez pas. Contactez support@tiptappay.com et nous le remplacerons.


Étapes de l'installation

- 1


Placer la signalétique imprimée sur la face avant de la base et l'alignement au niveau de trou découpé.


- 2

Placez l'appareil dans le joint avant et faites-le passer par l'avant de l'enseigne et de la base. Veillez à ce que la dénomination du dispositif soit à l'endroit.


- 3

Relier le joint arrière au joint avant jusqu'à ce qu'il soit bien serré. Répétez les étapes 2 et jusqu'à ce que tous les dispositifs soient en place.


- 4

Connectez les câbles USB-C à l'appareil et le câble USB-A à la prise murale.

