




Medium Counter Display Kit

Parts List & Assembly Instructions



Scan to watch the
assembly video









Weight: 3 lbs

For inquiries, contact us at
support@tiptappay.com

Updated: 08/12/25
[EN]


Parts List

GASKET SET						
Front Gasket	Back Gasket	Device	Signage	Display Base	10ft Cable	Wall Plug
						
X1	X1	X1	X1	X1	X1	X1
Make Your Display Portable! With <u>Battery Accessory kits</u> Contact sales@tiptappay.com to learn more. To be ordered separately.						


- Safety Precautions**
- 1). Please only use the components supplied by tiptap to power your devices and charge your battery.
 - 2). If a cable is frayed or worn, please do not use it. Contact support@tiptappay.com and we will replace it.

Installation Steps


- 1** Place printed signage on the front side of the base and lineup at the cutout hole.




- 2** Place device in the front gasket and put it through the front of the signage and base. Make sure the device denomination is right side up.



- 3** Connect the back gasket with the front gasket until snug.




- 4** Connect the USB-C to the device and the USB-A cable to the wall plug.





Kit de présentation pour comptoir moyen

Liste des pièces et instructions de montage



Poids: 3 lbs

Pour toute demande de renseignements, contactez-nous à l'adresse suivante :
support@tiptappay.com







Scan to watch the
assembly video



Mise à jour: 08/12/25
[FR]

Liste des pièces

SET DE GASKET

joint avant	Joint arrière	Appareil	Signe	Socle d'affichage	câble de 10 pieds	Prise murale
						
X1	X1	X1	X1	X1	X1	X1
Rendez votre présentoir portable! Avec les <u>kits d'accessoires pour batteries</u> . Contactez sales@tiptappay.com pour en savoir plus.						
A commander séparément.						


Précautions de sécurité

- 1). N'utilisez que les composants fournis par tiptap pour allumer votre appareil et charger votre batterie.
- 2). Si un câble est effiloché ou usé, ne l'utilisez pas. contactez support@tiptappay.com et nous le remplacerons.

Étapes de l'installation


1

Placer la signalétique imprimée sur la face avant de la base et l'alignement au niveau du trou découpé.




2

Placez l'appareil dans le joint avant et faites-le passer par l'avant de l'enseigne et de la base. Veillez à ce que la dénomination du dispositif soit à l'endroit.



3

Relier le joint arrière au joint avant jusqu'à ce qu'il soit bien serré.



4

Connectez les câbles USB-C à l'appareil et le câble USB-A à la prise murale.

