



Medium Framed Floorstand Display Kit

Parts List & Assembly Instructions






Weight: 22 lbs

For inquiries, contact us at
support@tiptappay.com


Updated: 08/12/25
[EN]

Parts List


GASKET SET					
Front Gasket  X4	Back Gasket  X4	Device  X4	Signage  X1	Floorstand  X1	Allen Key  X1
Backer Strips 14-1/2"  X4	10ft 3-way cable  X1	Wall Plug  X1	IMPORTANT! Screws are shipped in Floorstand legs. Remove with Allen Key before proceeding with assembly.		

Installation Steps


- 1 Twist legs into frame.




- 2 Attach Base to bottom of legs using screws and Allen Key.



- 3 Slide the printed signage through the top of the frame.




- 4 Insert the foam backer strips into the frame along the bottom, top, and sides at the back of the sign.




- 5 Place the fixed-denomination device in the front gasket and slide it through the front of the signage. Make sure the device denomination is right side up.

Connect the back gasket with the front gasket until snug. Repeat the previous steps until all devices are in place. Follow these same steps with the custom donation device, placing it in the cutout located on the top right of the signage.



- 6 Connect the USB-C cables to each device and the USB-A cable to the wall plug. Plug into power and start collecting! The custom donation device does not need to be plugged into a power source.



- 7 Cable Management Optional. For cable management, please use the complimentary zip ties supplied (or any available zip ties) to keep your cables organized.



Support de sol encadré moyen kit d'affichage

Liste des pieces et instructions d'assemblage






Poids: 21 lbs

Pour toute demande de renseignements, contactez-nous à l'adresse suivante : support@tiptappay.com


Updated: 08/12/25
[EN]

Liste des pièces


SET DE GASKET					
Joint avant  X4	Joint arrière  X4	Dispositif  X4	Signalisation  X1	Floorstand  X1	Clé Allen  X1
Bandes d'appui 14-1/2"  X4	Câble 3 voies de 10 pieds  X1	Prise murale  X1	IMPORTANT! Les vis sont expédiées dans les pattes. Les retirer à l'aide d'une clé Allen avant de procéder à l'assemblage		

Installation Steps


- 1 Tordre les pieds dans le cadre.




- 2 Fixer la base au bas des pieds à l'aide de vis d'une clé Allen.




- 3 Faites glisser la signalétique imprimée à travers la partie supérieure du cadre.




- 4 Insérez les bandes de mousse dans le cadre le long du fond et côtés à l'arrière du panneau.



- 5 Placez le dispositif de don fixe dans le joint avant et faites-le glisser à travers l'avant de la plaque signalétique. Assurez-vous que le nom du dispositif est bien visible.
Connectez le joint arrière au joint avant jusqu'à ce qu'ils soient bien serrés. Répétez les étapes précédentes jusqu'à ce que tous les dispositifs soient en place. Procédez de la même manière avec le dispositif de don personnalisé, en le plaçant dans la découpe située en haut à droite de la plaque signalétique



- 6 Connectez les câbles USB-C à chaque appareil et le câble USB-A à la prise murale. Branchez sur le secteur et commencez à collecter! L'appareil do don personnelisé n'a pas besoin d'être branché sur une source d'alimentation



- 7 Gestion des câbles en option. pour la gestion des câbles, veuillez utiliser les **colliers de serrage** fournis (ou tout autre collier de serrage disponible) pour garder vos câbles organisés.