



Medium Floorstand Kit

Parts List & Assembly Instructions





Weight: 22 lbs

For inquiries, contact us at
support@tiptappay.com


Updated: 08/12/25
[EN]

Parts List


GASKET SET					
Front Gasket  X4	Back Gasket  X4	terminal  X4	Signage  X1	Floorstand  X1	Allen Key  X1
Backer Strips 14-1/2"  X4	10ft 3-way cable  X1	Wall Plug  X1	IMPORTANT! Screws are shipped in Floorstand legs. Remove with Allen Key before proceeding with assembly.		

Installation Steps


- 1 Twist legs into frame.




- 2 Attach Base to bottom of legs using screws and Allen Key.



- 3 Slide the printed signage through the top of the frame.




- 4 Insert the foam backer strips into the frame along the bottom, top, and sides at the back of the sign.




- 5 Place the fixed-denomination terminal in the front gasket and slide it through the front of the signage. Make sure the terminal denomination is right side up.

Connect the back gasket with the front gasket until snug. Repeat the previous steps until all terminals are in place. Follow these same steps with the online giving terminal, placing it in the cutout located on the top right of the signage.



- 6 Connect the USB-C cables to each terminal and the USB-A cable to the wall plug. Plug into power and start collecting! The online giving terminal; does not need to be plugged into a power source.



- 7 Cable Management Optional. For cable management, please use the complimentary zip ties supplied (or any available zip ties) to keep your cables organized.