



Small Floorstand Kit

Parts List & Assembly Instructions



Scan to watch the
assembly video






Weight: 21 lbs

For inquiries, contact us at
support@tiptappay.com


Updated: 08/12/25
[EN]

Parts List


GASKET SET					
Front Gasket  X3	Back Gasket  X3	terminal  X3	Signage  X1	Floorstand  X1	Allen Key  X1
Backer Strips 14-1/2"  X3	10ft 3-way cable  X1	Wall Plug  X1	IMPORTANT! Screws are shipped in Floorstand legs. Remove with Allen Key before proceeding with assembly.		

Installation Steps


- 1 Twist legs into frame.




- 2 Attach Base to bottom of legs using screws and Allen Key.



- 3 Slide the printed signage through the top of the frame.




- 4 Insert the foam backer strips into the frame along the bottom and sides at the back of the sign.




- 5 Place terminal in the front gasket and put it through the front of the signage. Make sure the terminal denomination is right side up.

Connect the back gasket with the front gasket until snug. Repeat this step with the remaining terminals.



- 6 Connect the USB-C cables to each terminal and the USB-A cable to the wall plug. Plug into power and start collecting!



- 7 Cable Management Optional. For cable management, please use the complimentary zip ties supplied (or any available zip ties) to keep your cables organized.